

Document type **Technical Data Sheet**

Name	ECOTOP
Description	This vegetable oil blend has been designed to protect natural plasters for interior floorings, such as our PASTELLONE and ECO TERRAZZO. Being completely natural, it is particularly suitable to match the GREEN version of our products. It provides discreet water repellence that can be completed by the application of our MINERAL WAX.
Composition	Blend of vegetable seed oils. Contains linseed oil.
Appearance	Straw yellow, oily liquid
Packaging	5 L polyethylene packaging
Application	By hand, using a wax spreader or cloth
Type of Surface	Floors coated with PASTELLONE, ECO TERRAZZO
Dilution	Ready to use
Consumption	90 - 130 g/sqm
Drying	8 hours at 20°C (60°F) to the touch, 72 hours at 20°C (60°F) below the surface
Application temperatures	min 8 max 35°C – R.U. < 85% ca
VOC Classification	EU Directive 2004/42/CE: EU limit value for this product (cat A/I): 200 g/l (2010). This product contains less than 200 g/l of VOC.
Shelf life	24 months when stored according to the recommended guidelines
Storage	In original sealed packaging between 5° and 35°C in a dry, dark environment
Safety Norms	It is important to adhere to the prevailing safety and hygiene standards while using it. Refrain from disposing of the product in drains, water bodies, or on the ground. Always keep the product out of reach of children. In the event of ingestion, or allergic reaction seek medical assistance without delay and present the container or label.
Disposal	Product must be disposed of according to norms and regulations in force. Containers must be sent for recycling. Follow directions on the packaging.
Application Instructions	After completing all the sanding operations, pour ECOTOP onto the floor finish. Move the liquid on the surface using water-pulling spatulas or wax spreaders to allow uniform and deep penetration. ECOTOP can also be spread with a single disk machine. Approximately 4 hours later, when the floor no longer absorbs the material, the excess and superficial oil deposits must be removed by carefully passing dry rags, or preferably, by spreading sawdust on the floor. Drying with sawdust is important to avoid the creation of thick surface films by the deposit of excess material. WARNING: EXCESSES OF OIL ON THE SURFACE CAUSE STAINS. After a minimum of 36 hours, you can proceed with the application of MINERAL WAX.

We have drawn up the material presented above to the best of our technical and experiential knowledge. Nevertheless, our suggestions and recommendations are not guaranteed. All responsibility for the obtained results lies solely with the method and conditions adopted for the application of the product.